


Use and Care Guide

ProClean


Dryer Lint Removal Kit



Operation


1 CLEANING THE LINT TRAP

- Remove the lint trap from the dryer and insert the brush into the lint trap vent until you reach the bottom. Use a left to right and up and down motion to capture lint and debris. Continue up the vent until you reach the opening.



2 DISPOSING THE LINT AND DEBRIS


- Slowly remove the lint trap brush from the vent and dispose of the lint and debris. Repeat step 1 as necessary.



3 USING THE VACUUM HOSE ATTACHMENT


- Attach the vacuum hose attachment to your vacuum and insert it into the lint trap vent. Turn on the vacuum and clean up and down the lint trap vent.

NOTICE: If you experience decreased suction during cleaning, ensure debris is not lodged in the opening of the vacuum hose attachment.



4 REMOVING AND CLEANING THE DRYER DUCT

- Follow the dryer manufacturer's instructions to detach the dryer from the duct. Insert the dryer duct brush into the duct and push the brush forward and backward.




5 DISPOSING THE LINT AND DEBRIS

- Remove the dryer duct brush from the duct and dispose of the lint and debris. Repeat step 4 as necessary.



6 REATTACHING THE DRYER DUCT AND TESTING AIR FLOW

- Follow your dryer manufacturer's instructions to reattach the dryer duct back to the dryer. Turn on the dryer and ensure the air is flowing properly throughout the duct and exhausting air through the outside vent cap.



Safety Information

Never force the dryer duct brush through the duct. If it should become jammed, pull the brush away from the restricted area a few inches then slowly push forward again turning the brush in a clockwise motion.

Warranty

WHAT IS COVERED

All merchandise is warranted to be free from defects in workmanship and material for one year from the date of purchase. This includes normal wear and performance failure on items. The manufacturer will replace or repair at their option.

WHAT IS NOT COVERED

This warranty only covers normal wear and performance failure. It does not cover any malfunction, performance failure, or defect arising from the misuse, abuse, neglect, or modification of the product. Any damage or malfunction inflicted upon the product by the user or other external sources, or any failure to comply with the warnings and instructions, is not covered.

For further assistance visit www.DundasJafine.com.